

Pellon® Fusibles

1st Quality Interfacing For Light to Medium Weight Fabrics ST

Perfect interfacing for any blouse and dress weight fabric.

Use it in collars, cuffs, facings, pockets and detail areas.

Easy to Use

- Cut interfacing following pattern pieces. Trim 1/2" from seam allowances. Interfacing is pre-shrunk and ready to sew.
 - Place coated side of interfacing on wrong side of fabric. Cover with a damp press cloth.
 - Set iron at medium steam. To fuse, hold iron down firmly for 10-15 seconds. Lift and overlap slightly. Repeat fusing, moving iron in one direction across interfacing. Do not slide iron.
 - Iron fabric on right side to remove any excess moisture. As with all fusibles, it is a good idea to pre-test this interfacing on a scrap of fabric before fusing it to your garment. *Machine warm wash, delicate cycle. Use only non-chlorine bleach. Tumble dry low. Use warm iron if necessary. May be dry cleaned.
- Fiber Content: 100% Polyester